



ARTEMIS

**MECHANICAL SWAPPABLE BLUE SWITCH WIRELESS KEYBOARD
CB-GK-40**




USER MANUAL



OUTEMU BLUE SWITCHES



50 MILLION SWITCH LIFE



PER KEY RGB



SOFTWARE SUPPORT FOR WINDOWS



MCU FROM TAIWAN



68 KEYS KEYBOARD



3 MODES WIFI+BLUETOOTH+WIRED



Visit www.thecosmicbyte.com to download software for the keyboard

SPECIFICATIONS

- Type: 68 Key Keyboard
- Connection: Wireless 2.4Ghz/Bluetooth/Wired
- Battery Size: 3000mAH
- Charging Time: 7 Hours
- Switch: Mechanical
- Switch Colour: Blue
- Switch Life: 50 million
- Anti Ghosting: All Keys
- RGB Effects: 17 backlight effects
- Per Key RGB: Yes
- Cable: 1.7M Detachable Type C
- Size: 292*102*40mm
- Weight: 620 g ± 10g (Without Cable).
- Software Support: Windows
- Keycaps: Premium Double shot ABS
- PCB: Double Sided

FUNCTION KEYS

FN + F1: F1

FN + F2: F2

FN + F3: F3

FN + F4: F4

FN + F5: F5

FN + F6: F6

FN + F7: F7

FN + F8: F8

FN + F9: F9

FN + 0: F10

FN + -: F11

FN + =: F12

FN + [: PrtSc

FN +]: ScrLk

FN + ;: PauBr

FN + ': INS

FN + .: HOME

FN + /: END

FN + Win: Win lock

FN + PgDn: Volume -

FN + PguP: Volume +

FN + DEL: Switching Lighting Effect

FN + ~: Change Single Color Lighting

FN + \: User-Defined Lighting, during this mode, Default lighting effect:

ESC.ASDW. Direction keys up, down, left, and right, blue light

FN + ↑: Increase LED Brightness, 5 levels

FN + ↓ : Decrease LED Brightness, 5 levels

FN + → : Increase Speed of Dynamic Lighting, 3 levels

FN + ← : Decrease Speed of Dynamic Lighting, 3 levels

FN + Space : Lighting On/Off

FN + Q : Enters 2.4G wireless connection mode.

FN + "W/E/R" : Enter Bluetooth connection mode

FN + T : Enter USB wired connection mode

FN + TAB (Check current mode): FN+TAB short press, is used to detect the current keyboard working mode, and the corresponding keys Q / W / E / R / T will flash red for 2 seconds. For example, if you are currently working under E, Bluetooth BT2, the backlight of the E key will flash red for 2 seconds.

FN + ESC : Press FN+ESC for 3s-5s to restore the factory mode.

BACKLIGHT RECORDING MODE

To create a customized backlight mode, follow these steps:

1. Press the FN + Del keys and select the Backlight Recording Mode. This will light up the ESC, ASDW, and arrow keys in blue.
2. Press the FN + \ keys to enter the custom recording lighting mode.
3. Press each key and choose the desired colour for it.
4. Press the FN + \ keys again to exit the custom lighting recording mode.

That's it! Your customized backlight mode is now set up.

CONNECT USING 2.4G DONGLE

Step 1: Turn on the battery switch on the back of the keyboard. Press FN + Q to enter 2.4Ghz Dongle Connection mode.

Step 2: Press and hold FN + Q for 3 seconds to enter forced pairing mode, the Q key LED will blink in green, after successful pairing, LED will stop blinking.

Note: Pairing needs to be done only once. Keyboard will automatically connect to dongle the next time.

CONNECT USING BLUETOOTH

Step 1: Turn on the battery switch on the back of the keyboard. Press FN + W / E / R keys to switch between 3 Bluetooth devices, the corresponding key LED will flash in Blue at a frequency of 2/S. The keyboard will connect to a previously paired device within 15 seconds. If the connection is successful, the Blue LED of the key will turn off. If the connection is unsuccessful, the keyboard will sleep and all LEDs will turn off.

Step 2: Press and hold FN + W / E / R for 3 seconds to enter pairing mode of that channel, the corresponding key LED will blink in Blue, after successful pairing, LED will stop blinking.

Note: Pairing needs to be done only once. Keyboard will automatically connect to Bluetooth device the next time.

CONNECT USING WIRE

Press FN + T to enter wired connection mode.

SLEEP MODE

In wireless connection mode, if keyboard is idle for 180 seconds, the backlight will automatically turn off; if keyboard is idle for 30 minutes, it will enter deep sleep. Press any key to wake up the keyboard.

BATTERY INDICATOR

To check the battery level, press FN + Left CTRL keys.

The left CTRL key will light up in different colours to indicate.

RED LED - LOW Battery Level

YELLOW LED - MEDIUM Battery Level

GREEN LED - HIGH Battery Level

Indicator works in battery power supply mode only.

SUPPORT DETAILS

Phone: 07969273222 (Mon-Sat 10:00AM to 6:00 PM)
Email: cc@thecosmicbyte.com
FAQ: support.thecosmicbyte.com

WARRANTY

The Artemis Keyboard carries 1 Year warranty against manufacturing defects only. Physical, Water damage and Tampered products are not covered under warranty. Regular wear and tear from battery usage is not covered under warranty.



[Scan the QR code to know the Warranty Claim Procedure.](#)

FAQ'S

support.thecosmicbyte.com

REPLACING THE SWITCHES



The Artemis keyboard supports Swappable Outemu switches. This means that switches are not soldered onto the PCB, and you can easily remove and replace switches.

This helps to increase the life span of the keyboard. If any of the switch stops working just use the included Keycap and Switch puller to remove the keycap and switch and replace the switch with a new one.

You can also change the switch colour to any Blue, Red, Brown or other Outemu Swappable Switches to customize the keyboard as you require without any hassle.



SCAN QR CODE FOR
VIDEO GUIDE