




LAPTOP COOLING PAD



USER MANUAL

























SPECIFICATIONS

• Dimension 335*285*41.5 mm

• Fan Size 140*140*20mm(2 pcs)

Product Weight 620g

• Fan speed 1000±10%RPM

• USB QTY Two USB 2.0HUB

• Fan Noise level: 25dBA

• Current 0.32 A±10%

• Max Air Flow 74.35 CFM

Material ABS+Metal

FEATURES

- Dual 140 mm LED cooling fans to effectively and equally cool every corner of your laptop
- Rotatable switch for adjusting the fan wind speed
- Built-in Two USB ports allows you to connect other USB devices
- 7 levels of adjustable height for more viewing comfort
- Anti-skid mats, effectively prevents laptop from slipping off
- Optimized heat dissipation suitable for 14"-17" laptop

Operating Instructions:

- 1. Remove the Laptop Cooling Pad and Cable from the Packaging.
- 2. Adjust the height of the cooling pad using the 7 level height adjustment.
- 3. Open the front holder and place your laptop on the cooling pad.
- 4. Connect the USB cable to the cooling pad and your laptop.
- 5. Adjust the fan speed using the three dials.

Support details

Phone: 1800 31300 7700 (Mon-Fri 10am to 5PM)

Email: cc@thecosmicbyte.com FAQ: support.thecosmicbyte.com

Warranty

The cooling pad carries 1 Year warranty against manufacturing defects only. Physical, Water damage and Tampered products are not covered under warranty.



Scan the QR code to know the Warranty Claim Procedure.

FAQ's

support. the cosmic by te.com