



IGNIS

TRI MODE GAMING MOUSE



USER MANUAL

HIGHLIGHTS



Visit www.thecosmicbyte.com to download
the software for the mouse

- **Package Contents**

- Cosmic Byte Ignis Tri-Mode Gaming Mouse
- 2.4GHz USB Receiver
- USB-C Charging Cable (Paracord)
- User Manual

SPECIFICATIONS

Feature	Details
Model	Cosmic Byte Ignis
Length	121.1 mm
Width	68.1 mm
Height	39.52 mm
Weight	53.6g ±2g
Type	2.4GHz Wireless + Bluetooth + Wired
Interface	USB
Sensor	Pixart 3311IC
Acceleration	35G
Max Speed	300 IPS
Resolution	400–800–1600–3200–6400–12000 (Up to 24000 via software)
Polling Rate	1000Hz
Battery	400mAh rechargeable
Switches	Huano (20 million clicks lifespan)
Encoder	F-Switch
LED	None (Stealth Design)
Cable	1.5M Ultralight Paracord Cable
Compatibility	Windows XP, Vista, 7/8/10/11
Charging Spec	3.7V≤7.7mA

KEY FEATURES

- Ultra-lightweight ergonomic body
- Tri-mode connectivity: Wired, Wireless (2.4GHz), and Bluetooth
- Gaming-grade Pixart 3311 sensor
- DPI adjustments via bottom button
- Paracord cable for drag-free wired performance
- Long-lasting battery – ~52 hours on full charge
- Zero RGB for a stealth professional look

BUTTON FUNCTIONS

Button	Function
Left Click	Primary fire
Right Click	Secondary fire
Scroll Wheel	Scroll & middle click
Side Button 1	Forward
Side Button 2	Back
Bottom Button	DPI Cycle (6 Levels)

MODE SWITCHING

- **Mode Toggle (Bottom Switch):**

- Left: 2.4GHz Wireless Mode
- Center: Power OFF
- Right: Bluetooth Mode

- **Bluetooth Mode**

- Slide switch to **BT mode**.
- Press and hold **Left + Right + Scroll** buttons for 3 seconds.
- Mouse enters pairing mode (indicator blinks).
- Pair with your device — will appear as *CB Ignis*.

- **2.4GHz Wireless Mode**

- Slide switch to **2.4G mode**.
- Plug in the USB receiver.
- If the mouse doesn't respond:
 - Press and hold **Left + Right + Scroll** for 3 seconds to re-sync.

- **Wired Mode**

- Connect the USB-C cable to use the mouse in wired mode.
- Battery will automatically begin charging.

- **Battery & Charging**

Status	LED Indicator
--------	---------------

Charging	Steady Red
----------	------------

Fully Charged	Steady Green
---------------	--------------

- **Battery Life:** Approx. 52 hours
- **Charging Time:** 2–3 hours

TROUBLESHOOTING GUIDE

Q1: Mouse not responding in Bluetooth mode?

A: Ensure it's in BT mode. Hold **Left + Right + Scroll** for 3 seconds to enter pairing. Re-pair if needed.

Q2: Mouse not working in 2.4G mode?

A: Plug in the receiver. Hold **Left + Right + Scroll** for 3 seconds to re-sync.

Q3: DPI changes not working?

A: Press the DPI button located at the bottom of the mouse to cycle through preset levels.

Q4: Battery draining too fast?

A: Turn off the mouse when not in use. Avoid leaving it in pairing mode.

Q5: Cursor lagging or skipping?

A: Use on a smooth surface or mousepad. Ensure sufficient battery charge and check USB receiver placement.

Q6: Mouse not charging?

A: Use the included USB-C cable. Check for LED status—red while charging, green when full.

SOFTWARE SUPPORT

- DPI customization
- Macro recording
- DPI customization
- Macro recording

SUPPORT DETAILS

Customer Care Number: +91 7351615161 (Mon-Sat 10am to 6pm)

WhatsApp Support: +91 7351615161

Email: cc@thecosmicbyte.com

WARRANTY

- The Ignis Tri-Mode Gaming mouse carries 1 year warranty against manufacturing defects only.
- Physical, water damage and tampered products are not covered under warranty.



Scan the QR Code to know the Warranty Claim Procedure.