

# WIRED GAMING MOUSE



USER MANUAL



















# **SPECIFICATIONS**

Max Tracking Speed 220IPS

Acceleration 30G

Weight 40 Grams w/o cable

Max DPI 12400

Lowest DPI 200

Polling Rate 1000

Cable Length 1.5m Paracord (Feels like wireless)

Mouse Feet Type PTFE

Mouse Feet Thickness 0.6MM

Sensor 3327

Switch Type Huano 20M

Surface ABS

### **FEATURES**

Customisable RGB—The software allows you to customise the RGB effects with 12 modes. When connected to the PC, you can see a honeycomb texture on the left and right buttons.

Software Support—Customize all the mouse settings, macros, RGB, and other functions using software compatible with Windows OS.

Paracord Cable- Paracord cable is extremely lightweight, which makes the mouse feel like a wireless mouse.

Customisable DPI- Set different DPI levels from 200-12400 using the software. 20Mn Switches- The Pulse Mouse is equipped with Huano gaming switches, known for their exceptional durability. With a lifespan of 20mn, these switches

ensure your gaming companion will last for a long time, providing you with a reliable gaming experience.

1000Hz Polling Rate- The Pulse Mouse features a thrillingly high polling rate of 1000Hz. This determines the speed of the connection between the PC and the mouse, ensuring an exhilaratingly responsive gaming experience for our passionate gamers.

# STEPS TO CONNECT TO PC

- 1. Unpack the mouse from the packaging and remove the plastic film from the mouse's feet, if any.
- 2. Connect the mouse to the PC using the USB cable.
- 3. The mouse will be detected by Windows within 5-30 seconds.
- 4. Download the software for the mouse from the Cosmic Byte website.
- 5. Install the software (Note: Some antivirus may try to stop installation as software would not be updated in their database, so disable antivirus before installation)
- 6. Once installed restart your PC.
- 7. Your mouse is now ready for use. You can customize the functions of the mouse using the software

# **TROUBLESHOOTING**



#### 1. Unable to detect mouse on PC

**Ans:** Try connecting the mouse on a different USB port on the PC.

Try connecting the mouse directly on the motherboard USB port of the PC.

Connect the mouse to the extension adapter supplied.

### 2. Software does not detect the mouse.

**Ans:** Kindly uninstall all other mouse software previously installed on the PC. Restart the PC, unplug the Mouse and reinsert it again.

# SUPPORT DETAILS

Contact no: 07969273222 (Mon-Sat 10am to 6pm)

Email: cc@thecosmicbyte.com

# WARRANTY

The Pulse mouse carries 1 Year warranty against manufacturing defects only.

Physical, Water damage and Tampered products are not covered under warranty.

Regular wear and tear from battery usage is not covered under warranty.



Scan the QR code to know the Warranty Claim Procedure.

FAQ'S

support. the cosmic by te.com