

# WIRELESS GAMING HEADSET



**USER MANUAL** 































### **SPECIFICATIONS**

### **Speaker Parameters:**

Driver Unit: Φ50mm

Impedance:  $32\pm15\%\Omega$ 

Sensitivity: 113±3dB at 1KHz

Frequency Response: 20-20KHz

Rated Power: 20mW

Plug Type: USB dongle/Bluetooth 5.1

### **Detachable Mic Parameters:**

Mic Unit: Φ6mm

Impedance:  $\leq 2.2 \text{K}\Omega$ 

Directivity: Omnidirectional

Sensitivity: -42±3dB at 1KHz

Frequency Response: 100-10KHz

Battery capacity: 600mAh

Battery life: Upto 40h at 70% volume


Charging time: 3h

Distance: Upto 20m w/o obstacle

Charging cable: length 1m

Keep working while charging

#### **VOLUME CONTROL WHEEL**




#### MIC MODE AND PAIRING




### **POWER BUTTON**





- 1 Headset
- 2 Microphone
- 3 Dongle
- 4 Charging Cable

5 User Manual



# USING THE INFERNO WITH MOBILES & TABLETS

To use the headset with mobiles you can connect the headset using the USB dongle/Bluetooth.

Note: Some mobile might lead to low volume as they are unable to deliver the required power output to the dongle.

You can use the USB C to 3.5mm cable sold seperately if any sound issue with dongle or connect using bluetooth.

# USING THE INFERNO WITH PLAYSTATION 4 AND 5

To use the headset with PS4/PS5 you can connect the headset using the 3.5mm jack on the controller or through USB.

Volume can be controlled from the Playstation Audio Settings.

# USING THE INFERNO WITH XBOX

To use the headset with Xbox you can connect the headset using the 3.5mm jack on the controller. The headset will not work using USB on Xbox.

## Note: 3.5 mm Cable sold separately

#### LED INDICATION

USB dongle disconnected = Green LED Flashing

USB dongle connected = Green LED On

Headset disconnected = Blue LED Flashing

Headset connected in BT mode = Blue LED On

Headset connected in 2.4G mode = White LED on

Charging = Red LED On

Fully Charged= Green LED On

### **SUPPORT DETAILS**

Contact no: 07969273222 (Mon-Sat 10am to 6pm)

Email: cc@thecosmicbyte.com

### **WARRANTY**

The Inferno carries 1 Year warranty against manufacturing defects only.

Physical, Water damage and Tampered products are not covered under warranty.

Regular wear and tear from battery usage is not covered under warranty.



Scan the QR code to know the Warranty Claim Procedure.

FAQ'S

support. the cosmic by te.com