

## Stellaris Dongle & Gamepad Firmware Update – 1000Hz Polling Rate

Firmware Versions:

- Dongle: 2025-05-26\_ZXD2075\_Receiver\_V242

- Gamepad: 20250626\_ZXD2020\_JTD-GG06\_BLE\_HALL3D\_ZX652\_V174


Release Date: 26 May 2025

### Important Notice


Before starting the firmware update, please temporarily disable your antivirus software and turn off Windows Security → Real-Time Protection.

### How to Update the Stellaris Dongle Firmware


1. Download the dongle firmware from the Cosmic Byte website → product page → scroll to bottom → click “Firmware Update.”




Go to your Downloads folder. Right-click the ZIP file → select “Extract All.”




2. Open the extracted folder.




3. Double-click the firmware tool. If Windows shows a warning: click "More Info" → "Run Anyway."







4. Connect the dongle directly to your PC's USB port.





5. Once detected, the tool will show an "Update" button.




6. Click “Yes” to confirm the update.



7. Wait until the update completes. Do not disconnect the dongle during the process.





## How to Update the Stellaris Gamepad Firmware


8. Download the gamepad firmware from the Cosmic Byte website → product page → click “Firmware Update.”

IMAGES SHARED BY CB COMMUNITY




**OVERVIEW** USER MANUAL TROUBLESHOOTING ADDITIONAL INFORMATION FIRMWARE UPDATE


9. Extract the ZIP file by right-clicking → “Extract All.”




10. Open the extracted folder.




11. Double-click the firmware tool. If a Windows warning appears: click “More Info” → “Run Anyway.”






12. Turn OFF the controller.  
13. Press and hold the L3 button (press the left joystick).  
14. While holding L3, connect the controller to the PC using the USB cable.  
15. Open the firmware file: 20250626\_ZXD2020\_JTD-GG06\_BLE\_HALL3D\_ZX652\_V174.



16. Click “Update” to complete the gamepad firmware installation.





## Firmware Release Notes

This firmware update enhances the performance of the Cosmic Byte Stellaris Gamepad dongle. After updating, supported dongles will now operate at a 1000Hz polling rate, ensuring faster response time and improved gameplay accuracy.



### What's New – 1000Hz Polling Rate Support

- Dongle mode will now support a 1000Hz polling rate.
- This significantly reduces input latency and provides a smoother, more responsive gaming experience.

### Supported Dongle Batches

Serial Number (S/N)	Current Dongle Version
STETP202401	v1.215
STETP202407	v1.215
STETP202409	v1.215
STETP202411	v1.215