



ATLAS

TRI-MODE MOUSE



USER MANUAL

HIGHLIGHTS



Visit us at
www.thecosmicbyte.com
to download the software for the mouse

SPECIFICATIONS

1. **Mouse:** 5 Keys + 3 Buttons
2. **Connection:** Tri-mode – Type-C Wired, Bluetooth, and 2.4G Wireless
3. **Sensor:** PAW3311
4. **Polling Rate:** Max 1000Hz (133Hz in Bluetooth mode)
5. **Compatibility:** Windows XP and later, Android 9.0 and later, Linux, and macOS
6. **Built-in Battery:** 500mAh Lithium Polymer
7. **Working Current:** Approximately 6.6mA
8. **DPI Range:** Up to 12,000 DPI (hardware)
9. **Weight:** 56 Grams
10. **Dimensions:** 123 × 62.3 × 38 mm
11. **Left and Right Switch:** Huano, rated for 20 million clicks
12. **Mouse Foot-pad Material:** PTFE
13. **Software:** Windows Only
14. **Cable:** 1.8m Paracord Cable with USB extension

FUNCTIONS

1. Mode Switching:

- Press the **M** button briefly to toggle between Bluetooth and 2.4G modes.
- **L2 Indicator Light:**
 - **Green:** 2.4G Mode
 - **Blue:** Bluetooth Mode
- To enter Bluetooth pairing mode, press and hold the **M** button for about 2 seconds. The L2 indicator will flash blue rapidly.

1. DPI Adjustment:

- Press the **D** button briefly to cycle through 5 DPI levels.
- Each level corresponds to an **L2 indicator color:**
 - **800 DPI:** Red
 - **1600 DPI (Default):** Green
 - **2400 DPI:** Blue
 - **5000 DPI:** Purple
 - **12000 DPI:** Yellow

1. Power Switch:

- Use the ON/OFF switch to toggle the battery power.

1. Custom Settings:


- The 5 mouse keys can be personalized using the software.

1. Connection Priority:

- The wired connection takes priority over other modes.

1. L1 Indicator Status:

- **Flashing Red:** Low Battery
- **Steady Blue:** Charging
- **Steady Green:** Charging Complete



GENERAL TROUBLESHOOTING STEPS

1. Mouse is Unresponsive:

- Ensure the mouse is switched ON. Check the ON/OFF switch position.
- Confirm the battery is charged. If the **L1 indicator** flashes red, connect the mouse to a power source to charge it.
- Verify the connection mode (Bluetooth, 2.4G, or Wired):
 - For **Bluetooth Mode**: Ensure the mouse is paired correctly. Press and hold the **M** button for 2 seconds to re-enter pairing mode.
 - For **2.4G Wireless Mode**: Confirm the USB receiver is properly connected to the device.
 - For **Wired Mode**: Check the Type-C cable connection.

1. Cursor Movement is Erratic:

- Adjust the DPI setting using the **D** button to match your preferred sensitivity.
- Clean the mouse sensor and the surface beneath it to remove dust or debris.
- Use the mouse on a suitable, non-reflective surface for optimal performance.

1. Bluetooth Connection Issues:

- Ensure the mouse is in Bluetooth mode (L2 indicator shows blue).
- Check if the Bluetooth on your device is enabled and the mouse is listed in paired devices.
- Restart both the mouse and the device, then attempt to pair again.

1. 2.4G Wireless Connection Issues:

- Ensure the USB receiver is securely plugged into the device.
- If the connection fails, re-pair the mouse by switching to Bluetooth mode and back to 2.4G mode using the **M** button.
- Try using the USB receiver on a different port or device.

1. Charging Problems:

- Verify the Type-C cable is properly connected and the power source is functional.
- Check the **L1 indicator**:
 - **Blue light**: Charging in progress.
 - **Green light**: Fully charged.

6. Buttons or Functions Not Working:

- Confirm the driver software is installed and updated on your device.
- Use the driver software to reset any personalized settings that may conflict.
- Test the mouse on another device to determine if the issue is hardware-related.

7. Battery Drains Quickly:

- Reduce unnecessary use of high DPI levels if not required.
- Switch off the mouse when not in use using the ON/OFF switch.

8. Driver Software Issues:

- Reinstall the driver software and restart your device.
- Ensure the driver software is compatible with your operating system version.

9. Indicator Lights are Not Functioning:

- Check the mouse connection and ensure the battery is not depleted.
- If the issue persists, reset the mouse by turning it off and back on.

10. Reset the Mouse:

- Turn the mouse off and disconnect it from all connections (Bluetooth, 2.4G, and Wired).
- Wait for 10 seconds, then reconnect and power it back on.

SUPPORT DETAILS

Contact no: +91 73 5161 5161 (Mon-Sat 10am to 6pm)

Email: cc@thecosmicbyte.com

WARRANTY

- The Atlas mouse carries 1 Year warranty against manufacturing defects only.
- Physical, Water damage and Tampered products are not covered under warranty.
- Regular wear and tear from battery usage is not covered under warranty.



Scan the QR code to know the Warranty Claim Procedure.