

CosmicByte[®]
switch to GOD MODE

CosmoBuds K200

TRUE WIRELESS GAMING EARBUDS



USER MANUAL



**BLUETOOTH
5.3**

**FUTURISTIC
MECHANICAL
DESIGN**

**40 HOURS
PLAYBACK TIME**



**EASY TOUCH
CONTROL**

**38 MS
ULTRA-LOW
LATENCY**

**HIGH DEFINITION
AUDIO**

**BREATHING
LED LIGHTS**



**GOD MODE[®]
MUSIC MODE**



**IPX5
SWEAT &
WATERPROOF**



**TOUCH
CONTROLS**



**INSTANT
PAIRING**



**VOICE
ASSISTANT**




**ENC
MICROPHONE**




SPECIFICATIONS

Bluetooth Version	V5.3
Low latency	38 ms under game mode
Driver size	10mm
Frequency Response	20Hz-20Khz
SNR	98dB
Music playtime	Up to 7 hours per charge (at 70% volume) Up to 10 hours per charge (at 50% volume)
Talk time	up to 7 hours
Standby time	100 days
Transmission Range	10m
Battery Earbuds	40 mAh
Charging case	400 mAh
Charging time	About 1.5 hours
Charging interface	Type-C
Fast Charging	15 min = 100 min playtime


PACKAGE CONTENTS




TOUCH BUTTON
LED INDICATOR




CHARGING CASE



CHARGING CABLE



USER MANUAL



EARTIPS X 3 PAIRS

CHARGING



HOW TO CHARGE THE COSMOBUDS X200

- During use if the Red LED light on the TWS flashes with voice reminder "Battery Level Low", it indicates that the TWS battery level is low.
- To charge place the earbuds into the charging case.
- The Red LED on the earbuds will turn on indicating that the earbuds are charging.
- Once the earbuds are charged the LED on it will turn off.


CHARGING CASE

To charge the case plug it to a 5V/1A charger using the included Type C Cable.


LED INDICATOR

Red LED: Charging

LED Off: Fully Charged




5V / 40 MA (EARBUDS)



5V / 400 MA (CHARGING CASE)

PAIRING



PAIRING THE X200 TO YOUR BLUETOOTH DEVICE

FIRST TIME USER- SMART POWER ON

- a. Once you remove the earbuds from the charging case, they will automatically enter pairing mode.
- b. Visit your mobile Bluetooth settings, New Device and connect to "CosmoBuds X200"
- c. The CosmoBuds X200 will automatically pair with your mobile and is ready for use.

B) MANUAL PAIRING- MANUAL POWER ON

- a. Long touch on both the earbuds simultaneously until the LED lights on the earbuds start to flash.
- b. The earbuds will connect to each other and enter pairing mode.
- c. Visit your mobile Bluetooth settings, New Device and connect to "Cosmo Buds X200 Enter '0000' if the passkey is asked
- d. The CosmoBuds X200 will automatically pair with your mobile and is ready for use.

INSTANT ON AND PAIR (IOP™)

The CosmoBuds X200 feature instant on and pairing feature. Once you have connected the Earbuds to your device it will automatically connect to your mobile device as soon as you remove it from the case.

NOTE:

Pairing mode lasts for 5 minutes. If the pairing time is missed, then you will need to reconnect the earbuds and follow the above-mentioned procedure. X200 remembers previously connected devices; once switched on, the earbuds automatically reconnect to the previously connected device.

USING SINGLE EARBUD ONLY

Please note that both the earbuds can be used in mono mode.

Step 1: Use either of the two options; Smart Power On or Manual Power On for switching on the desired earbud

Step 2: The selected earbud will automatically enter the connection mode.

Step 3: Turn on Bluetooth on your phone/media device and search for 'Cosmo Buds X200' to connect.

NOTE:

To switch to Stereo mode, simply take out the other earbud from the case. It will automatically power on and pair with the previously selected earbud, enabling Stereo usage.

SMART POWER OFF

Simply place the X200 into the charging case in correct orientation, they will switch off automatically and enter charging mode.

MANUAL POWER OFF

Long touch on either earbud for five seconds to manually switch off the X200.

TOUCH FUNCTIONS



MUSIC PLAYBACK MODE



PREVIOUS TRACK:

DOUBLE TOUCH THE LEFT EARBUDS.

NEXT TRACK:

DOUBLE TOUCH THE RIGHT EARBUDS.

PAUSE/RESUME PLAYING:

SINGLE TOUCH ON EITHER EARBUD.

CALLING MODE



ANSWER INCOMING CALL:

SINGLE TOUCH ON EITHER EARBUD.

REJECT INCOMING CALL:

LONG TOUCH FOR 2 SECONDS

HANG UP CALL:

SINGLE TOUCH ON EITHER EARBUD

GOD MODE/MUSIC MODE

Triple Touch the RIGHT earbud to switch between Game Mode and Music Mode

GOD Mode enables 38ms low latency sound and enables accurate sound positioning.

Music Mode enables the integrated music engine for High Fidelity Audio and Bass.

VOICE ASSISTANT




Triple Touch the LEFT earbud to activate your phone's default smart voice assistant.



NOTE:

VOLUME CANNOT BE CONTROLLED VIA EARBUDS AND CAN ONLY BE ADJUSTED VIA PHONE/MEDIA DEVICE

TROUBLESHOOTING




FACTORY RESETTING THE COSMOBUDS X200

Perform the Factory Reset in case you face any difficulty while operating your X200 Earbuds

Note: Before performing reset, clear "CosmoBuds X200" from pairing device history by forgetting the TWS



SCAN QR CODE FOR
TROUBLESHOOT VIDEO



Step 1: Unpair the CosmoBuds X200 from all your mobile devices before performing reset. Go to Bluetooth Settings and "Forget the Device"

Step 2: Remove both the earbuds from the charging case.

Step 3: Long Touch both the earbuds simultaneously for 5-6 seconds. The LED light on both earbuds will blink 3 times and turn off..

Step 4: Place the earbuds back in the charging case and wait for 5 seconds.

Step 5: CosmoBuds X200 is now ready for use.

TOUBLESHOOT AUDIO ONLY FROM ONE EARBUD

If you are unable to hear sound from any one earbud, it means that the earbuds are not connected with each other. The LED lights on the earbud not connected will blink continuously in BLUE and RED color.



SCAN QR CODE FOR
TROUBLESHOOT VIDEO



Steps to Pair the Earbuds

Step 1: Forget the earbuds in Bluetooth settings of your mobile device.

Step 2: Remove the earbuds from the charging case, the blue and red led on both earbuds will be flashing.

Step 3: Double touch both the earbuds top touch area simultaneously and wait for 5 seconds for the LED to turn off and turn on any one earbud.

Step 4: Now pair the earbuds with your mobile device. Once connected both LED on the earbuds will turn off.

Step 5: Earbuds are ready for use.

POTENTIAL PROBLEM

Potential Problem	Solution
IF ONE EARBUD IS NOT WORKING	Perform "TOUBLESHOOT AUDIO ONLY FROM ONE EARBUD" steps
IF EARBUDS ARE UNABLE TO CONNECT	Perform the "FACTORY RESETTING THE COSMOBUDS X200" & "TOUBLESHOOT AUDIO ONLY FROM ONE EARBUD" both steps
IF EARBUDS DISCONNECT DURING PHONE CALL	Charge the earbuds or perform "FACTORY RESETTING THE COSMOBUDS X200"
IF THERE ARE OTHER ISSUES WITH USAGE	Place the earbuds back into the charging case and try using them again or perform "FACTORY RESETTING THE COSMOBUDS X200"

WARNING




- Please follow the instructions to operate.
- Please charge the ear-buds with input power below 5V/1A in order to protect the battery.
- Please don't use the ear-buds in extreme temperatures.
- Please don't use the product near water.
- Please keep the product away from heat sources, as the heat may damage it.
- Don't jam the ports such as charger port, LED port, etc.
- It is recommended to utilize the product below the maximum volume in order to protect hearing and extend the ear-buds' service life.
- Never disassemble or modify the device to avoid any permanent damage or danger.
- Do not use the device during a thunderstorm to avoid irregular function or risk of electric shock.
- Don't use harsh chemicals to clean the device.

Advisable:

The earbuds start at a 100% volume and it may need to be reduced when the earbuds are switched on at first. This can be done by using the volume control on the phone/ media device.


REMOVE VOLUME LIMIT



HOW TO REMOVE VOLUME LIMIT ON ANDROID AND IOS TO INCREASE THE VOLUME

ios


1. Go to Settings > Music
2. Move the slider of Sound Check to the left to turn it off.



THIS WILL REMOVE THE IOS VOLUME LIMIT SO THAT
EARBUDS CAN PLAY AT FULL VOLUME.

ANDROID

1. Go to Settings > Bluetooth
2. Click on CosmoBuds X200
3. In the options turn off option Sync Volume with phone




NOTE: ABOVE OPTION MAY NOT BE AVAILABLE IN ALL ANDROID PHONES. DEPENDING ON THE PHONE MODEL AND MANUFACTURER.


REMOVE SPOTIFY & AMAZON MUSIC VOLUME LIMIT.

Spotify and Amazon Music does not use system volume limit so you have to go to app settings and turn off Audio Normalisation to remove the limit.

SPOTIFY



AMAZON MUSIC



SUPPORT DETAILS

Phone: 1800 31300 7700 (Mon-Fri 10am to 5PM)
Email: cc@thecosmicbyte.com
FAQ: support.thecosmicbyte.com

WARRANTY

The Cosmobuds X200 carries 1 Year warranty against manufacturing defects only. Physical, Water damage and Tampered products are not covered under warranty. Regular wear and tear from battery usage is not covered under warranty.



[Scan the QR code to know the Warranty Claim Procedure.](#)

FAQ'S

support.thecosmicbyte.com

CERTIFICATIONS



EARBUDS



CHARGING CASE