

CosmicByte[®]
switch to GOD MODE

CosmoBuds K1000

TRUE WIRELESS GAMING EARBUDS



USER MANUAL

**FUTURISTIC
MECHANICAL
DESIGN**

**EASY TOUCH
CONTROL**

**38 MS
ULTRA-LOW
LATENCY**

BATTERY DISPLAY

**HIGH DEFINITION
AUDIO**

**40 HOURS
PLAYBACK TIME**

**BLUETOOTH
5.3**



**GOD MODE[®]
MUSIC MODE**



**IPX5
SWEAT &
WATERPROOF**



**TOUCH
CONTROLS**



**INSTANT
PAIRING**



**VOICE
ASSISTANT**




**ENC
MICROPHONE**



SPECIFICATIONS


Bluetooth Version	V5.3
Low latency	38 ms under game mode
Driver size	10mm
Frequency Response	20Hz-20Khz
SNR	98dB
Music playtime	Up to 7 hours per charge (at 70% volume)
	Up to 10 hours per charge (at 50% volume)
Talk time	up to 7 hours
Standby time	100 days
Transmission Range	10m
Battery Earbuds	40 mAh
Charging case	400 mAh
Charging time	About 1.5 hours
Charging interface	Type-C
Fast Charging	15 min = 100 min playtime

PACKAGE CONTENTS




LED INDICATOR

TOUCH BUTTON




CHARGING CASE



CHARGING CABLE



USER MANUAL



EARTIPS X 3 PAIRS

CHARGING




HOW TO CHARGE THE COSMOBUDS X100


- During use if the LED light on the TWS flashes with voice reminder "Battery Level Low", it indicates that the TWS battery level is low.
- To charge place the earbuds into the charging case.
- The LED on the earbuds will turn on indicating that the earbuds are charging.
- Once the earbuds are charged the LED on it will turn off.

CHARGING CASE

To charge the case plug it to a 5V/1A charger using the included Type C Cable. Once the indicator on the charging case Displays 100% charge you can disconnect the charger.




5V / 40 MA (EARBUDS)



5V / 400 MA (CHARGING CASE)

PAIRING



PAIRING THE X100 TO YOUR BLUETOOTH DEVICE

A) FIRST TIME USER- SMART POWER ON

- a. Once you remove the earbuds from the charging case, they will automatically enter pairing mode.
- b. Visit your mobile Bluetooth settings, New Device and connect to "CosmoBuds X100"
- c. The CosmoBuds X100 will automatically pair with your mobile and is ready for use.

B) MANUAL PAIRING- MANUAL POWER ON

- a. Long pinch the touch buttons on both the earbuds simultaneously until the LED lights on the earbuds start to flash.
- b. The earbuds will connect to each other and enter pairing mode.
- c. Visit your mobile Bluetooth settings, New Device and connect to "CosmoBuds X100"
- d. The CosmoBuds X100 will automatically pair with your mobile and is ready for use.

INSTANT ON AND PAIR (IOP™)

The CosmoBuds X100 feature instant on and pairing feature. Once you have connected the Earbuds to your device it will automatically connect to your mobile device as soon as you remove it from the case.

NOTE:

Pairing mode lasts for 5 minutes. If the pairing time is missed, then you will need to reconnect the earbuds and follow the above-mentioned procedure. X100 remembers previously connected devices; once switched on, the earbuds automatically reconnect to the previously connected device.

USING SINGLE EARBUD ONLY

Please note that both the earbuds can be used in mono mode.

Step 1: Use either of the two options; Smart Power On or Manual Power On for switching on the desired earbud

Step 2: The selected earbud will automatically enter the connection mode.

Step 3: Turn on Bluetooth on your phone/media device and search for 'Cosmo Buds X100' to connect.

NOTE:

To switch to Stereo mode, simply take out the other earbud from the case. It will automatically power on and pair with the previously selected earbud, enabling Stereo usage.

SMART POWER OFF

Simply place the X100 into the charging case in correct orientation, they will switch off automatically and enter charging mode.

MANUAL POWER OFF

Long pinch the touch button on either earbud for five seconds to manually switch off the X100.

TOUCH FUNCTIONS



MUSIC PLAYBACK MODE



PREVIOUS TRACK:
DOUBLE PINCH THE LEFT EARBUDS.

NEXT TRACK:
DOUBLE PINCH THE RIGHT EARBUDS.

PAUSE/RESUME PLAYING:
SINGLE PINCH ON EITHER EARBUD.

CALLING MODE



ANSWER INCOMING CALL:
SINGLE PINCH ON EITHER EARBUD.

REJECT INCOMING CALL:
LONG PINCH FOR 2 SECONDS.

HANG UP CALL:
SINGLE PINCH ON EITHER EARBUD.

GOD MODE/MUSIC MODE

Triple Pinch the right earbud to switch between Game Mode and Music Mode


GOD Mode enables 38ms low latency sound and enables accurate sound positioning.

Music Mode enables the integrated music engine for High Fidelity Audio and Bass.

VOICE ASSISTANT




Triple Pinch the left earbud to activate your phone's default smart voice assistant.



NOTE:
VOLUME CANNOT BE CONTROLLED VIA EARBUDS AND CAN ONLY
BE ADJUSTED VIA PHONE/MEDIA DEVICE

TROUBLESHOOTING



FACTORY RESETTING THE COSMOBUDS X100

Perform the Factory Reset in case you face any difficulty while operating your X100 Earbuds



SCAN QR CODE FOR
TROUBLESHOOT VIDEO



**LONG PINCH
BOTH EARBUDS**

Step 1: Unpair the CosmoBuds X100 from all your mobile devices before performing reset. Go to Bluetooth Settings and "Forget the Device"

Step 2: Remove both the earbuds from the charging case.

Step 3: Long Pinch both the earbuds simultaneously for 5-6 seconds. The LED light on both earbuds will blink 3 times and turn off.

Step 4: Place the earbuds back in the charging case and wait for 5 seconds.


Step 5: CosmoBuds X100 is now ready for use.

TOUBLESHOOT AUDIO ONLY FROM ONE EARBUD

If you are unable to hear sound from any one earbud, perform the pairing steps mentioned below



SCAN QR CODE FOR
TROUBLESHOOT VIDEO



**DOUBLE PINCH
BOTH EARBUDS**
SIMULTANEOUSLY

Steps to Pair the Earbuds

Step 1: Forget the earbuds in Bluetooth settings of your mobile device.

Step 2: Remove the earbuds from the charging case, the running led on both earbuds will be on.

Step 3: Double pinch both the earbuds top touch area simultaneously and wait for 5 seconds for the LED to turn off and turn on any one earbud.

Step 4: Now pair the earbuds with your mobile device. Once connected both LED on the earbuds will turn off.

Step 5: Earbuds are ready for use.

POTENTIAL PROBLEM

Potential Problem	Solution
<ul style="list-style-type: none">• IF ONE EARBUD IS NOT WORKING	Perform "TOUBLESHOOT AUDIO ONLY FROM ONE EARBUD" steps
<ul style="list-style-type: none">• IF EARBUDS ARE UNABLE TO CONNECT	Perform the "FACTORY RESETTING THE COSMOBUDS X100" & "TOUBLESHOOT AUDIO ONLY FROM ONE EARBUD" both steps
<ul style="list-style-type: none">• IF EARBUDS DISCONNECT DURING PHONE CALL	Charge the earbuds or perform "FACTORY RESETTING THE COSMOBUDS X100"
<ul style="list-style-type: none">• IF THERE ARE OTHER ISSUES WITH USAGE	Place the earbuds back into the charging case and try using them again or perform "FACTORY RESETTING THE COSMOBUDS X100"

WARNING




- Please follow the instructions to operate.
- Please charge the ear-buds with input power below 5V/1A in order to protect the battery.
- Please don't use the ear-buds in extreme temperatures.
- Please don't use the product near water.
- Please keep the product away from heat sources, as the heat may damage it.
- Don't jam the ports such as charger port, LED port, etc.
- It is recommended to utilize the product below the maximum volume in order to protect hearing and extend the ear-buds' service life.
- Never disassemble or modify the device to avoid any permanent damage or danger.
- Do not use the device during a thunderstorm to avoid irregular function or risk of electric shock.
- Don't use harsh chemicals to clean the device.

Advisable:

The earbuds start at a 100% volume and it may need to be reduced when the earbuds are switched on at first. This can be done by using the volume control on the phone/ media device.


REMOVE VOLUME LIMIT



HOW TO REMOVE VOLUME LIMIT ON ANDROID AND IOS TO INCREASE THE VOLUME

ios


1. Go to Settings > Music
2. Move the slider of Sound Check to the left to turn it off.



THIS WILL REMOVE THE IOS VOLUME LIMIT SO THAT
EARBUDS CAN PLAY AT FULL VOLUME.

ANDROID

1. Go to Settings > Bluetooth
2. Click on CosmoBuds X100
3. In the options turn off option Sync Volume with phone




NOTE: ABOVE OPTION MAY NOT BE AVAILABLE IN ALL ANDROID PHONES. DEPENDING ON THE PHONE MODEL AND MANUFACTURER.


REMOVE SPOTIFY & AMAZON MUSIC VOLUME LIMIT.

Spotify and Amazon Music does not use system volume limit so you have to go to app settings and turn off Audio Normalisation to remove the limit.

SPOTIFY



AMAZON MUSIC



SUPPORT DETAILS

Phone: 1800 31300 7700 (Mon-Fri 10am to 5PM)
Email: cc@thecosmicbyte.com
FAQ: support.thecosmicbyte.com

WARRANTY

The Cosmobuds X100 carries 1 Year warranty against manufacturing defects only. Physical, Water damage and Tampered products are not covered under warranty. Regular wear and tear from battery usage is not covered under warranty.



[Scan the QR code to know the Warranty Claim Procedure.](#)

FAQ'S

support.thecosmicbyte.com

CERTIFICATIONS



EARBUDS



CHARGING CASE